



NÁVOD NA MONTÁŽ HT-402M




1 x 1 	2 x 4 	
A x 8 	B x 4 	C x 1
D x 8 	E x 8 	F x 4

1



2



3

